



How to Replace the Seat Mount Assembly

This guide illustrates how to replace the seat mount assembly.





TOOLS:

- T27 Wrench (1)
- 11mm Wrench (1)



PARTS:

- Replacement seat mount assembly. (1)
-

Step 1 — Remove the end cap.



- Using the T27 wrench and the 11mm wrench, remove the 4 screws and accompanying nuts (2 on the top and 2 on the bottom) of the slide rail end cap.

Step 2 — Remove the seat assembly.



- Pull the seat off the end of the slide rail.
- Flip the seat assembly over to expose the seat mounting screws.

Step 3 — Remove the seat from the seat mount assembly.



- Using the T27 wrench, remove the four mounting screws holding the seat to the seat mount assembly.
- NOTE the four seat mounting screws are different from the four end cap screws.

Step 4 — Reassembly.



- Install the seat on the seat mount assembly.
- Install the seat assembly back onto the slide rail.
- Install the end cap.