




ROGUE®

ECHO ROWER

PARTS LIST

Diagram #	Part#	Description
37	IP0917-37	ST4.2 x 19mm Self Tapping Screw
83	IP0917-83	1/4-20 x 12mm Torx Head Screw
87	IP0917-87	M4 x 10mm Socket Head Screw Foot Strap Bracket
88	IP0917-88	Foot Strap Rivet
89	IP0917-89	Foot Strap Bracket
91	IP0917-91	Pedal Fixing Plate
92	IP0917-92	M4 x 10mm Cross Head Screw
93	IP0917-143	Flex Footslide
95	IP0917-95	Pedal Left Bottom
96	IP0917-96	Pedal Left Upper
97	IP0917-97	Mating Bolt - Foot Strap Assembly
98	IP0917-98	Strap Buckle
99	IP0917-144	Replacement Strap