


ROGUE®

ECHO ROWER



ROGUE®

ECHO ROWER

PARTS LIST

Diagram #	Part#	Description
12	IP0917-12	M4 x 10mm Socket Head Screw
37	IP0917-37	ST4.2 x 19mm Self Tapping Screw
40	IP0917-40	Chain Cover Frame
41	IP0917-41	M5 x 8mm Socket Head Screw Chain Cover
42	IP0917-42	M8 x 80mm Torx Head Screw Console Support Bottom
43	IP0917-43	M8 x 75mm Torx Head Screw Console Support Top
44	IP0917-153	Monitor Mast Assembly Left
45	IP0917-154	Monitor Mast Assembly Right
46	IP0917-46	M8 x 1.25mm Lock Nut
64	IP0917-64	1/4-20 Nylock Nut
69	IP0917-69	Chain Frame Decorative Cover
70	IP0917-70	Indicator
71	IP0917-71	Indicator Flat Washer
72	IP0917-72	Indicator Spring
73	IP0917-73	Indicator Spring Cross Head Screw
74	IP0917-74	M2 Monitor
83	IP0917-83	1/4-20 x 12mm Torx Head Screw
117	IP0917-117	Fan Cover Left Support Washer
118	IP0917-118	Console Support Washer
135	IP0917-135	Handlebar
136	IP0917-136	U Ring
137	IP0917-137	Chain Connector U Ring Side
138	IP0917-138	Chain Connector Chain Side
139	IP0917-139	Chain
141	IP0917-141	Chain Cover Assembly Spring Washer