


ROGUE®

ECHO ROWER



ROGUE®

ECHO ROWER

PARTS LIST

Diagram #	Part#	Description
1	IP0917-1	Fan Cover Left
2	IP0917-2	Magnet Ring
3	IP0917-3	Fan Wheel Rivet
4	IP0917-4	Fan Wheel Fixing Plate
5	IP0917-5	Fan Wheel Weight Clip
6	IP0917-6	Fan Wheel
7	IP0917-7	Mesh Cover
8	IP0917-8	M4 x 0.7mm Hex Nut Mesh Connector
9	IP0917-9	Mesh Cover Connector Nut Side
10	IP0917-10	Mesh Cover Connector Screw Side
11	IP0917-11	M4 x 50mm Cross Head Screw Mesh Connector
12	IP0917-12	M4 x 10mm Socket Head Screw
13	IP0917-13	Wave Washer Stopper
14	IP0917-14	Wave Washer
15	IP0917-15	ST3.9 x 10mm Self Tapping Cross Head Screw
16	IP0917-16	Fixing Spiral Plate
17	IP0917-142	Fan Cover Right
18	IP0917-18	M5 x 75mm Cross Head Screw Right Cover
19	IP0917-19	Rotational Spiral Plate
21	IP0917-21	Damper Adjuster
22	IP0917-22	Round Fixing Plate
121	IP0917-121	Mesh Side Cover