


ROGUE®

ECHO SKI



ROGUE®

ECHO SKI PARTS LIST

SCHEMATIC-1

DIAGRAM #	PART #	DESCRIPTION
1	IP0944-1	ECHO SKI Mainframe
2	IP0944-2	ECHO SKI Right Arm
3	IP0944-3	ECHO SKI Left Arm
4	IP0944-4	ECHO SKI Upper Connector
5	IP0944-5	Cover Plate
6	IP0944-6	Rotational Axle Assembly
7	IP0944-7	ECHO SKI Shaft Bearing
8	IP0944-8	One Way Bearing
9	IP0944-9	Long Spacer
10	IP0944-10	Short Spacer
11	IP0917-13	Wave Washer Stopper
12	IP0917-7	Mesh Cover
13	IP0944-13	Round Mesh Plate
14	IP0917-18	M5x75mm Cross Head Screw
15	IP0917-42	M8x80mm Torx Head Screw Monitor Support Bottom
16	IP0917-43	M8x75mm Torx Head Screw Monitor Support Top
17	IP0944-17	M8x95mm Torx Head Screw
18	IP0944-18-SS	1/4-20x1.5" Torx Head Screw - Stainless
19	IP0944-19-SS	1/4-20x1.25" Torx Head Screw - Stainless
20	IP0917-111	1/4-20x16mm Torx Head Screw
21	IP0944-21-SS	1/4-20x0.75" Torx Head Screw - Stainless
22	IP0917-83	1/4-20x12mm Torx Head Screw
23	IP0944-23-SS	1/4-20x0.375" Torx Head Screw - Stainless
24	IP0917-57	M8x20mm Socket Head Screw Front Foot Top
25	IP0917-12	M4x10mm Socket Head Screw
26	IP0944-26	M4x10mm Torx Head Self Tapping Screw
27	IP0917-15	ST3.9x10mm Self Tapping Cross Head Screw
28	IP0944-28-SS	#10x0.5" Cross Head Screw - Stainless
29	IP0917-11	M4x50mm Cross Head Screw Mesh Connector
30	IP0944-30-SS	ST2.9x10mm Cross Head Screw - Stainless
31	IP0944-31-SS	#4x1" Cross Head Self Tapping Screw - Stainless
32	IP0944-32	ST4.2x15mm Cross Head Self Tapping Screw
33	IP0917-46	M8x1.25mm Lock Nut

DIAGRAM #	PART #	DESCRIPTION
34	IP0917-64	1/4-20 Nylock Nut
35	IP0944-35	1/4-20 Hex Nut
36	IP0917-8	M4 x 0.7mm Hex Nut Mesh Connector
37	IP0917-14	Wave Washer
38	IP0944-38	Fan Axel Wave Washer
39	IP0917-117	Fan Cover Support Washer
40	IP0917-36	3/8-16 Lock Nut
41	IP0944-41	ECHO SKI Inside Fan Cover
42	IP0944-42	Outside Fan Cover
43	IP0944-43	ECHO SKI Flywheel
44	IP0944-44	Flywheel Fixing Plate
45	IP0944-45	Rotational Spiral Plate
46	IP0944-46	Adjusting Dampener
47	IP0944-47	Round Fixing Plate
48	IP0917-47	Turf Tire
49	IP0944-49	ECHO SKI Bearing Housing
50	IP0944-50	ECHO SKI Cord Spool
51	IP0944-51	ECHO SKI Cord Pulley Bracket
52	IP0944-52	ECHO SKI Top Cover
53	IP0944-53	ECHO SKI Shock Cord Pulley
54	IP0944-54	ECHO SKI Cord Pulley
55	IP0944-55	ECHO SKI Cord Pulley Spacer
56	IP0944-56	Handle Holder
57	IP0944-57	Handle
58	IP0944-58	Handle Cord Holder
59	IP0944-59	Left Outer Handle Cover
60	IP0944-60	Left Inner Handle Cover
61	IP0944-61	Right Outer Handle Cover
62	IP0944-62	Right Inner Handle Cover
63	IP0944-63	ECHO SKI Monitor Holder
64	IP0944-64	ECHO SKI Main Frame Handle
65	IP0944-65	ECHO SKI Footpad
66	IP0944-66	ECHO SKI Rubber Bearing Pad

ROGUE®

ECHO SKI PARTS LIST

SCHEMATIC-1

DIAGRAM #	PART #	DESCRIPTION
67	IP0917-33	Endcap
68	IP0917-10	Mesh Cover Connector Screw Side
69	IP0917-9	Mesh Cover Connector Nut Side
70	IP0917-31	Generator Sensor
71	IP0944-71	M2 SKI Monitor
72	IP0944-72	Elastic Cord
73	IP0944-73	Handle Cord
74	IP0944-74	Zip Tie
75	IP0944-75	ECHO SKI Left Wheel Bracket
76	IP0944-76	ECHO SKI Right Wheel Bracket
77	IP0944-77	ECHO SKI Left Upper Connecting Bracket
78	IP0944-78	ECHO SKI Right Upper Connecting Bracket
79	IP0944-79	ECHO SKI Hardware Kit
80	IP0944-80	Echo SKI Box
81	IP0944-81	Front Generator Cover
82	IP0944-82	Rear Generator Cover
83	IP0944-83	ST4.2x25mm Cross Head Screw