
ROGUE® FM-HR 80" FUNCTIONAL TRAINER TWIN WEIGHT STACK



IMPORTANT SAFETY INFORMATION

DISCLAIMER:

Resistance training, gymnastics training, and activities at height are potentially dangerous and may lead to severe injury or even death. Use common sense when training, obtain instruction in the proper execution of movements, and understand your limitations. This equipment must only be used by competent and responsible persons. Obtaining instruction in appropriate techniques and methods of use is your own responsibility. You assume all risks and responsibilities for all damage, injury or death which may occur during or following incorrect use of this equipment in any matter whatsoever. Rogue Fitness bears no liability beyond the replacement value of the equipment in question.

WARNING:


THIS RACK MUST BE BOLTED TO THE FLOOR BEFORE USE.
MINIMUM TWO PEOPLE REQUIRED FOR SAFE ASSEMBLY.
MISUSE OF THIS RACK CAN RESULT IN SEVERE INJURY.

Both Rogue Fitness and buyer disclaim any express or implied warranty, including, without limitation, warranties or merchantability and/or fitness for a particular purpose with respect to the equipment. Buyer assumes all liability to use of equipment.

TABLE OF CONTENTS


FM-HR TWIN

Included Tools	.3
Included Parts	.4
Assembly1	[3





FM-HR SHROUD KIT


Included Tools	3
Included Parts	10
Assembly	28 41





INCLUDED TOOLS
































































^{*} Only included if Half Rack Feet were purchased at checkout.








































































^{*} Items may look different than drawings shown. Style depends on selection made at checkout.














































































INCLUDED PARTS: SHROUD KIT


































INCLUDED PARTS: SHROUD KIT






1" HARDWARE LENGTH GUIDE


Note:


• 1" x 5" [45] and 1" x 4-3/4" [46] Bolts shown to scale below to help differientate variations in length.




Tools Required:

- 3/8" Allen Key
- Multi Tool
- If modifying existing rack with Add-on Kit, skip Steps 1-5 and proceed to **STEP 6**.
- Secure the Pulley Swivel to the Trolley using the preinstalled hardware included with the Pulley Swivel.
- Tighten until there is light friction in the joint, while still allowing the Pulley Swivel to hinge freely.
- Ensure Pulley Swivel is oriented as shown in the correct image.










IMPORTANT:


- DO NOT USE TOOLS TO TIGHTEN THROUGHOUT ASSEMBLY UNLESS OTHERWISE SPECIFIED.
- While pulling the handle triggers, slide Swivel Trolley RH [7] and Swivel Trolley LH [8] onto two Monster Uprights [1].
- Note the orientation of Swivel Trolleys in relation to the feet at bottom of uprights.
- Slide about halfway down Upright and release triggers to lock pop pins in place when the viewing window is showing number 24.






- Refer to overview image to plan assembly and ensure ample floor space is alloted.
- Lay down all parts on a non-abrasive surface in the orientation shown below.
- Position the footplates of uprights approximately 55" apart.
- Note orientation of Swivel Trolleys and Upright feet in relation to the ground.
- Connect Uprights to Crossmembers using 1" x 4-3/4" Hex Bolts [46], 1" x 5" Hex Bolt [45], 1" Flat Washers [48], 1" Lock Washers [49], and 1" Hex Nuts [50]. Note: Use 1" x 5" Hex Bolt [45] on front lower holes.
- If Half Rack Feet [9] were purchased, install them in place of Flat Washers on bottom of Uprights as shown in Detail views.
- HAND-TIGHTEN ONLY









IMPORTANT:


- For safety, we recommend the remainder of these instructions be completed by 2 or 3 people.
- Have two people stand one assembled panel up first.
- One person stabilizes the first panel while the other stands up the second panel.
- One or two people should stabilize both panels, ensuring panels don't fall while another person assembles the spanning Crossmember in **STEP 5**.







Tools Required:


- 3/8" Allen Key
- Attach 43" Spanning Crossmember [3] to middle Uprights using 1" x 4-3/4" Hex Bolt [46], 1" Flat Washers [48], 1" Lock Washers [49], and 1" Hex Nuts [50].






- If modifying existing RM rack with add-on kit, begin following assembly instructions.
- If modifying existing RM rack, start by leaving 1" x 4-3/4" Hex Bolts in place, remove all four lower Lock Washers and Hex Nuts from rear Uprights as shown in 6-A. Attach Low Row Crossmember [18] and re-assemble the hardware.
- If you assembled RM rack using these instructions, use hardware pictured in 6-A to attach Low Row Crossmember [18] to the rear uprights.







Tools Required:


- 7/32" Allen Key, 9/16" Wrench
- Swivel Trolleys [7,8] need to be calibrated for your specific rack.
- Keeping the Swivel Trolleys locked in place, tighten the Button Head Screws shown in **7-A** using 7/32" Allen Key until looseness or "wobble" is gone.
- Unlock pop pins and roll Trolleys up and down Upright several inches to feel tightness. If wobble persists, tighten the Screws in **7-A** again. If any friction is felt, Trolleys are too tight and Screws should be loosened a quarter turn.
- Once calibrated, tighten both rollers on rear of Trolleys using Allen Key and Wrench.






- For ease of assembly, pull the pop-pin and remove Foot Catch [15] from Low Row Foot Plate Assembly [16] as shown in detail view (right).
- Attach Foot Plate Assembly [16] and Low Row Connector Plate [17] to Low Row Crossmember [6] using indicated 5/8" and 1/2" hardware below.








Tools Required:


- 1-1/2" Wrench
- Attach Weight Stack Shroud Brackets [64] and Bottom Weight Stack Spacers [22] to Rear Low Crossmembers [5] by using 1" x 5" Hex Bolts [45], 1" Flat Washers [48], 1" Lock Washers [49], and 1" Hex Nuts [50].
- Fully tighten 1" vertical hardware in 9-A.

• Secure Rear 3X3 Upright [2] to Low Row Crossmember by attaching 5/8" x 4-1/2" Hex Bolts [51], 5/8" Lock Washers [52], and 5/8" Hex Nuts [53].

Note:

Ensure notches on Bottom Weight Stack
 Spacers are oriented towards the back of rack.







• Place Weight Stack Bumpers [24] over outer 1" holes on the Weight Stack Spacer and insert Guide Rods [18] until they rest on top of the Rear Low Crossmember.

Note:


• Allow guide rods to angle outward while completing weight stack assembly on the following steps.







Note:

- This step is best accomplished with two or three people.
- One at a time, carefully stack all included 10LB Weight Stack Plates [20] down the Guide Rods [18], ensuring not to drop them.
- Once 28 weights are stacked on each side, slide the Weight Stack Stem [19] down the Guide Rods until resting on top of weight stack.
- Ensure '20LB' Weight Stack Stickers on the top plate of Weight Stack Stems are bothing facing inward towards the middle of the rack.









- Slide Top Weight Stack Spacers [23] on top of guide rods with notches oriented towards the rear of rack.
- Position Guide Rods vertically. Slide in the Weight stack Shroud Brackets above the Guide Rods. Attach components to Rear Top Crossmembers using 1" x 5" Hex Bolts, 1" Flat Washers, Lock Washers, and Nuts.
- Attach Weight Stack Pulley Top Bumpers through center holes on Top Weight Stack Spacers using 1/2" x 4-1/2" Socket Head Screws, 1/2" Flat Washers, and 1/2" Thin Nylock Nuts.


Note:


• Shroud Bracket [65] only included if shroud kit was purchased.







• Bolt Lat Bar Hanger [15], Lat Pulldown Pulley Bracket [14], and Top Center Crossmember [10] to Spanning Crossmember using 1" x 5" Hex Bolts [45], 1" Lock Washers [49], and 1" Hex Nuts [50] as shown in 13-A.










- Attach Top Rear Angle Crossmember RH and Top Side Pulley Assembly RH in position shown using 1" x 5" Hex Bolts, 1" x 3/8" Pulley Bracket Spacers, 1" Lock Washers, and 1" Hex Nuts.
- Attach Top Rear Angle Crossmember LH and Top Side Pulley Assembly LH in position shown using 1" x 5" Hex Bolts, 1" x 3/8" Pulley Bracket Spacers, 1" Lock Washers, and 1" Hex Nuts.
- Ensure rear plates of Top Rear Angle Crossmembers are placed inside of slot of the Rear Upright as shown in DETAIL.









- Secure 4.5" Pulley [31] and 3/4" x 1" Cable Retainer [32] inside Rear 3X3 Upright using 3 /8" x 3-1/2" Button Head Screws [60] and 3/8" Thin Nylock Nuts [61] through the indicated holes.
- Bolt Connector Plates [13] to Top Center Crossmember [10] and Rear 3X3 Upright [2] using 5/8" x 4-1/2" Hex Bolts [51], 5/8" Lock Washers [52], and 5/8" Hex Nuts [53].










STEP 16 (SHROUD KIT ONLY)

Tools Required:

- 5/32" Allen Key
- If Shroud Kit was not purchased, proceed to **STEP 17**.
- Attach Weight Stack Nameplate Shrouds [68] to Weight Stack Shroud Brackets [65] using 1/4" x 5/8" Button Head Screws [76] and fully tighten.









Bolt Bottom Side Pulley Assembly - RH
[28] and -LH [29] to the 24" Rear Low
Crossmembers using 1" x 5" Hex Bolts [45],
1" x 3/8" Pulley Bracket Spacers [47], 1"
Flat Washers [48], 1" Lock Washers [49],
and 1" Hex Nuts [50] as shown.

Note:

• Hardware is assembled through the 4th and 6th holes on 24" Rear Low Crossmembers [5] with the bolt heads oriented inside of rack as shown.







- Unwind Trolley Cable (Blue Tag) [33] to remove twists/kinks.
- Starting on the Right Side of the rack, screw bolt ends of Trolley Cables [33] into stop block on back of RH Trolley [7].
- Loosen the hex nut if needed to ensure approximately 1/2" of threads are showing between the bolt head and nut.
- Feed cable up to the Top Side Pulley Assembly RH, feeding around the pulley shown in **18-B** and then immediately feed the cable around the pulley at the rear of the Top Side Pulley Assembly RH as shown in **18-C**.


• Continuing down towards the Weight Stack, feed cable around the large 6" Pulley located on top of the Weight Stack Stem. **Tip:** a flathead screwdriver may be used to help guide cable through turn 16.


Note:

• Arrow directions and numbers on parts shown in **18-D** do not correspond to numbering sequence. (Will be represented by 16 and 17).













- Continue feeding around the first pulley on Top Rear Angle Crossmember RH following the arrow indicator (6,7) directions towards the back of the rack.
- Feed cable around the next angled pulley at the back of the Top Rear Angle Cross member RH and downward.
- Hold the Peanut Pulley [30] in the air, ensuring the arrow stickers correspond to diagram 19-B.
- Feed the cable down and around the upper pulley of Peanut Pulley and then back up towards the Top Rear Angle Crossmember RH [11].










- From the Peanut Pulley, continue to feed the cable up and around the rear pulley in the Top Rear Angle Crossmember RH [11] following arrows 12 and 13.
- Continue towards the outside of the rack and feed cable around the angled pulley shown in **20-B** and down towards the Bottom Side Pulley Assembly RH [**28**].
- Note: If shroud is installed, run the cable inside of the shroud.










- Note: Skip from arrow 15 to arrow 18 and continue on.
- Feed the Ball End of Trolley Cable [33] around the pulley on Bottom Pulley Assembly (arrows 18 & 19) and continue towards the front pulley.
- Continue around the front pulley and then up and out through the Swivel Trolley - RH
 [7].













Tools Required:


- 3/32" Allen Key & 5/8" Wrench
- Completely disassemble the loose Clevis included with cable by unscrewing set screws and Split Threaded Insert, and remove blue tag on end of cable.
- Slide parts over the ball on cable as shown on **22-B**.
- Insert Grommet into non-threaded side of Split Threaded Insert and screw Clevis End on threaded side using 5/8" Wrench.
- Slide Plastic Stop forward and align outer holes with threaded holes on Clevis End and re-insert Set Screws. Fully tighten Set Screws.













Tools Required:


- 3/32" Allen Key, and 5/8" Wrench
- Follow **STEPS 18**—**22** again to assemble the remaining Trolley Cable (blue tag) on the **Left Hand side of rack**.





Note:

- Completely unwind and straighten out Lat Pull Cable [34] to remove any twists/kinks prior to installation.
- Next assemble the Lat Pull/Low Row cable indicated by the yellow indicator on Ball End of cable and corresponding yellow arrows shown in **STEPS 24–25.**
- Feed the Ball End of Lat Pull Cable [34] up and over the pulley in Lat Pulldown Pulley Bracket [14] and then towards the back of the rack.
- Feed around the pulley in the top of Rear 3X3 Upright [2] and then all the way down, ensuring cable runs INSIDE THE UPRIGHT.
- I Ensure cable sits in groove of pulley and runs beneath the spacer as shown.













Tools Required:


- 7/32" Allen Key & 9/16" Wrench
- Disassemble pulley located at the bottom of Rear 3X3 upright and feed cable around pulley.
- Reassemble pulley while pulling cable up toward Peanut Pulley.
- Feed cable around bottom pulley in the Peanut Pulley [30] and then back down again.
- Feed cable out through the front of the Low Row Footplate Assembly [16] and assemble Clevis onto Ball End of cable.















Tools Required:

- 1-1/2" Wrench, 1/8" Allen Key
- If modifying existing rack with add-on kit, skip to **26-B**.
- Place Key Washer over the Key Nut on the Plate Storage Post shown in **Detail** view.
- Assemble Plate Storage Pins [37] on rear Monster Uprights at desired hole heights.
- Slide Plate Storage Spacers [38] all the way down Plate Storage Pins with the set screws oriented on the bottom of Spacers as shown in 26-C.
- Fully tighten set screws using 1/8" Allen Key.












Tools Required:


- All
- Tighten ALL loose hardware on the entire rack.
- Starting with no weight selected on the Weight Stack, check cables by pulling on each clevis.
- If cables are too tight or loose, adjust accordingly by loosening or tightening the lower 1/2" Jam Nuts on back side of the Trolleys [7,8].





- Apply the Weight Stack Number Labels
 [35] on the front of the Weight Stack Plates, approximately 3.5" from the edge of plate.
- Attach key ring on Selector Pin Lanyard
 [21] to front hole on pulley plate of the
 Weight Stack Stem [19].
- Attach Single Handle Attachments [41] to Swivel Trolleys using included Carabiners.
- Attach Lat Bar [39] to Lat Pull down clevis attachment point.
- Re-insert the Footplate [15] into Low Row Footplate Assembly [16] and attach Standard Grip Triangle [40] to clevis.















STEP 29 (SHROUD ASSEMBLY)

- Align Rear Shroud RH [63] and Rear Shroud LH [64] with corresponding holes on Rear 3X3 Upright [2] and bolt Shrouds to Upright using 5/8" x 4-1/4" Hex Bolts [73], 5/8" Lock Washers [74] and 5/8" Hex Nuts [75].
- Align top and bottom 1/4" holes on Shrouds and bolt together using 1/4" x 5/8" Button Head Screws [76].











STEP 30 (SHROUD ASSEMBLY)


• Attach Weight Stack Rear Shroud - RH [66] and Weight Stack Rear Shroud - LH [67] on rear uprights by placing 1" Lock Washers [71] and 1" Hex Nuts [72] through window cutouts on shrouds and secure using 1" Flat Washers [70] and 1" x 4-3/4" Hex Bolts [69].








INCLUDED MONSTER STRIP


- *Hardware and tools not included for installing Monster Strips [62].
- 3/8" x 2-1/2" Wood Lag Screws and 3/8" Flat Washers (not included) are recommended if mounting Strip to wall or wood stud.
- 15/64" Diameter drill bit recommended if using 3/8" Lag Screws.
- Identify stud in wall and mark desired height of top hole. Drill pilot hole in marked location.
- Put thread-side of screw through washer then screw through top hole at the back of the Strip into wall until wood but do not fully tighten.
- Let strip hang and ensure it is square using a level then mark locations of the remaining holes.
- Hold strip to the side as shown in 31-B and drill pilot holes in the marked locations.
- Put thread side of screw through the washer then screw through bottom 3/8" hole in back of Strip into the wall loosely.
- Screw in the remaining two Lag Screws and fully tighten all screws.
- If attempting to secure Strip to concrete or other material, the buyer is responsible for using correct hardware.
- It is the buyer's responsibility to install strip in a location and with hardware capable of supporting the aggregate weight of strip, all gear mounted or stored, and any person using it.
- If you are not confident in your mechanical skills, please seek the help of a professional to perform the installation.












CABLE MAINTENANCE

Over time, the cables within the system may experience some normal inelastic stretching. Follow the below instructions to re-tighten the cables.

STEP 1

Tools Required:

- Multi Tool
- Tighten both Trolley Cable bolt heads up towards the stop blocks on Swivel Trolleys.
- If cable system is tight, no further calibration is needed. If cables still have slack, proceed to **STEP 2.**



STEP 2

Tools Required:

- Multi Tool, 7/32" Allen Key
- Remove the Rear Center Shrouds.
- Remove Cable Retainers and hardware shown in **33-A** on Rear Pulley Assembly and move Pulley up by one hole.
- Re-adjust the height of the Trolley Cable Bolts to calibrate the cable tightness.

• If slack persists, continue moving Retainers and Pulley up by one hole and testing until cables are taught but not pulling up the weight stacks.

Note:

• If installing pulley on the uppermost hole of Rear Pulley Assembly, the lower Cable Retainers are not needed.

