


ROGUE[®]

DOG SLED 1.2



IMPORTANT SAFETY INFORMATION

DISCLAIMER:

Resistance training, gymnastics training, and activities at height are potentially dangerous and may lead to severe injury or even death. Use common sense when training, obtain instruction in the proper execution of movements, and understand your limitations. This equipment must only be used by competent and responsible persons. Obtaining instruction in appropriate techniques and methods of use is your own responsibility. You assume all risks and responsibilities for all damage, injury or death which may occur during or following incorrect use of this equipment in any matter whatsoever. Rogue Fitness bears no liability beyond the replacement value of the equipment in question.

WARNING:

MISUSE OF THIS PRODUCT CAN RESULT IN SEVERE INJURY. Both Rogue Fitness and buyer disclaim any express or implied warranty, including, without limitation, warranties or merchantability and/or fitness for a particular purpose with respect to the equipment. Buyer assumes all liability to use of equipment.

INCLUDED PARTS

Note: Images not shown at scale

1


Qty: 1x



Dog Sled Pan

2

Qty: 2x




Dog Sled Upright Handle

3

Qty: 1x

*



Dog Sled Post

4


Qty: 2x



Dog Sled Ski

5

Qty: 4x




5/8" x 3.5" Hex Bolt

6

Qty: 1x


*



5/8" x 1.5" Hex Bolt

7

Qty: 4x




5/8" Flat Washer

8

Qty: 5x

*



5/8" Lock Washer

9

Qty: 4x





5/8" Hex Nut

* Hardware comes installed in Dog Sled Post.



STEP 1

- Secure the Dog Sled Skis [4] to both sides of the Dog Sled Pan [1] using 5/8" x 3.5" Hex Bolts [5], 5/8" Flat Washers [7], 5/8" Lock Washers [8], and 5/8" Hex Nuts [9].
- **Note:** Hardware for **STEP 1-B** comes installed in the Dog Sled Post [3] and needs to be removed before installation as shown in **DETAIL**.
- Attach Dog Sled Post [3] to Dog Sled Pan [1] using 5/8" x 1.5" Hex Bolt [6] and 5/8" Lock Washer [8].



STEP 2

- Insert Dog Sled Upright Handle [2] into Dog Sled Skis [4].
- Place desired plates (not included) on Dog Sled Post [3].



ROGUE



**SCAN FOR
INSTRUCTIONS**



**IRON GAME
PROGRAMMING**

ER00565-1